

# User Guide

## W-AIR 150

### Local contacts

Add a contact to local phonebook

1. Press **Menu** key and select **Contacts**
2. Press **More** Soft key -> **Add contact**
3. Fill in the fields, when ready, press **Save** Soft key.

Assign a speed dial number to a local contact:

1. In Contacts, select a contact that you wish to assign a speed dial number to
2. Select **More** -> **Speed dial**
3. Select a speed dial number (from 2 to 9) that you wish to assign to the selected contact
4. Press **Add** Soft key.

### Make a call

Manually: enter the number from idle and press the green **Off-hook** key.

Dial a speed dial number: make a long press (>2 seconds) from idle on the speed dial key (from 2 to 9) assigned to the contact.

Call from call history:

1. Press **Menu** key and select **Call list**
2. Select a call from the list
3. Press the green **Off-hook** key

Call from shared company phonebooks

1. Press **Menu** key and select **Central directory**
2. Press **Search** Soft key
3. Enter the number or the name and press **Selection** key
4. Select a contact that you wish to call (in case a contact has several phone numbers, a green arrow is displayed near the contact; use **Navigation** keys to select the phone number)
5. Press the green **Off-hook** key

*Shared company phonebooks must be set up by user via Collaboration or by the PBX administrator.*

### Adjust volume, enable speaker, mute the microphone

Mute the microphone: press **Mute** key during a call.

Adjust the volume: press **Volume Up / Down** keys during a call.

Turn on the Speaker mode: press the **Speaker** key during a call. Press the key to answer a ringing call in Speaker mode.

### Push to talk (PTT)

Press **Menu** key, select **Settings** -> **PTT** -> **On** to enable the feature. Press and hold **Mute** key and say your message. Your message is transmitted to other W-AIR 100/150 handsets in the network.

### Hold / Second call

Press **Hold** Soft key during a call to put a call on hold.

Second call: enter the number to call or press **Selection** key to access *Contacts* or *Central directory*, then press the green **Off-hook** key.

Swap: when you have one active call and one call on hold, press **Swap** Soft key to swap between them.

*Note: this device supports up to two active calls / lines.*

### Call transfer

Blind transfer (the desired party/extension is not notified of the impending transfer)

1. Press **Transfer** Soft key during a call (the call is put on hold)
2. Enter the number or press **Selection** key to search in *Contacts* or *Central directory*
3. Press **Transfer** Soft key.

Attended transfer (the desired party/extension is notified)

1. Press **Transfer** Soft key during a call (the call is put on hold)
2. Enter the number or press **Selection** key to search in *Contacts* or *Central directory*
3. Press the green **Off-hook** key
4. Press **Transfer** Soft key to transfer the call.

### Conference call

1. Press **Conf.** Soft key during a call (the call is put on hold)
2. Enter the number or press **Selection** key to search in *Contacts* or *Central directory*
3. Press the green **Off-hook** key
4. When the third party answers, press **Conf.** Soft key.

### Access Voicemail

Press **Voicemail** key (Key 1) and hold it for at least 2 seconds to access Voicemail and follow the audio prompts.

### Phone and audio settings

- For Language settings, LED signal, Power save, Auto-answer, Vibration settings: press **Menu** key and select **Settings**.
- For Ring volume, Ring melody, Key sound, Coverage warning, Charger warning, Bluetooth and other audio settings: press **Menu** key and select **Audio settings**.
- To set Alarm clock: press **Menu** key and select **Alarm clock**.



## Packing list

- 1 x W-AIR 150 handset with Lithium-Ion battery
- 1 x charger
- 1 x A/C adapter
- 1 x belt clip and belt clip cover
- 1 x pull cord and pull cord cover

## Safety information

<https://www.wildix.com/safety-information/>

## Put into operation

1. Open the battery compartment by turning the lock lever
2. Lift the battery cover and remove the battery
3. Remove the protective foil from the battery contacts
4. Reinsert the battery and close the battery compartment
5. Connect the A/C adapter to the charger
6. Place the phone into the charger and fully charge the battery (this may take up to 6 hours; charging status is indicated on the display).

The blue LED of the charger is on when the phone is properly placed into the charger and charging.

## Keypad instruction

## Turn on / turn off

- Press and hold the **On-hook** key for at least 2 seconds to turn on.
- Press and hold the **On-hook** key for at least 3 seconds to turn off.

## Register to the base

1. Press the **Menu** key
2. Select **Connectivity**
3. Select **Register**,
4. Select an empty slot and enter the PIN (by default, 0000)
5. Press **OK**.

## Login

1. Dial 99 and press the green **Off-hook** key
2. Enter your extension number
3. Enter the first five characters of your password
4. Press 1 when prompted.

To enter your password from the phone's keypad: press once an alphanumeric key corresponding to a letter which you need to enter; press the star button (\*) to enter any special character.



Example: Password: 4Ag7\$ZI@  
Enter: 4247\*



Wildix Partner

full guide online:



[www.wildix.com](http://www.wildix.com)